EXHIBIT 1 VR-101 Revision X

Franklin Fueling Systems (Phil-Tite/EBW/FFS) Phase I Vapor Recovery System Equipment List

NOTE:

(Gas/E85) = Identifies that these components are approved for standard gasoline and E85 fuel blends. (Gas) = Identifies that these components are only approved for standard gasoline fuel blends.

Equipment
Spill Container
(Phil-Tite Series
Spill Containore

Manufacturer/Model Number

Phil-Tite 85000 and 85000-1 Series (Gas/E85)

Spill Containers)

85W0X and 85W0X-1 legend:

W represented by:

1=replacement spill container

X represented by:

0 = product spill container

0-EXT = product spill container w extension collar

1 = vapor spill container

1-EXT = vapor spill container w extension collar

Spill Container (Defender Series Spill Containers) EBW Defender 705 Series (Gas/E85)

Defender 705 Series Legend (Gas/E85) 7055XYZAB where XYZAB is represented by:

X = containment

4 = singe wall

5 = double wall

Y = installation

2 = multiport bucket

5 = direct bury

Z = interstitial monitoring method

0 = no sensor/gauge (i.e. single wall)

1 = I2 monitor (float gauge, visual)

2 = TSP-ULS (electronic sensor)

A = spill container base thread

0 = NPSM (straight thread)

1 = NPT (taper thread)

B = drain valve

1 = with drain valve (typical on product/fill side)

2 = without drain valve (typical on vapor side)

Spill Container (EBW Series Spill Containers)

EBW 7XX-49Y-0Z (Gas)

XX indicates spill bucket gallon size:

= 5 Gallon 05

15 = 15 Gallon

Y indicates level and base material:

= grade level with cast iron base (5 gallon)

2 = below grade level with cast iron base **Equipment**

Manufacturer/Model Number

(5 and 15 gallon)

Z indicates drain valve:

1 = drain valve

2 = no drain valve

Spill Container Lid (Phil-Tite Series Spill

iner Lid Phil-Tite 85011 (Gas/E85)

(Not required with sump configuration lid, see Figure 2B in Exhibit 2)

Containers)

Spill Container Lid

EBW 7054401X (Gas/E85)

(Defender and EBW Series

X = Lid Color, Varies

Spill Containers)

Replacement Drain Valve (Phil-Tite Series Phil-Tite 85400 (Gas/E85)

Spill Containers)
Replacement

EBW 70533729 (Gas/E85)

Drain Valve (Defender Series Spill Containers)

EBW 70533719 (Gas)

70533729 (Gas/E85)

Replacement
Drain Valve
(EBW Series
Spill Container)

Drain Valve Blank Kit

(EBW Series Spill Container)

EBW 90022

Drain Valve Isolation

Kit

(EBW Series Spill Containers) EBW 70825501

Drain Valve Isolation

Test Kit (EBW Series Spill Containers) EBW 90079

Product Adaptor

Phil-Tite SWF-100-B (Gas)

Phil-Tite SWF-100-SS (Gas/E85)

Vapor Adaptor Phil-Tite SWV-101-B (Gas)

Phil-Tite SWV-101-SS (Gas/E85)

Riser Adaptor Phil-Tite M/F 4X4 (Gas/E85)

Phil-Tite M/F 4X4-R (Gas/E85)

Riser Support Bracket Phil-Tite M 1600 (Gas/E85)

Equipment Manufacturer/Model Number

FFS

Drop Tube Riser

Clamp

(Defender Series Spill

Containers)

Dust Cap Morrison Brothers 323C-0100ACEVR (vapor) (Gas/E85)

> Morrison Brothers 305C-0100ACEVR (product)(Gas/E85)

OPW 1711T-EVR (vapor) (Gas/E85) OPW 634TT-EVR (product) (Gas/E85)

70550901EC (Gas/E85)

OPW 634LPC (product) (Gas) OPW 1711LPC (vapor) (Gas)

CSP1-634LPC (product) (Gas) CompX CompX CSP3-1711LPC (vapor) (Gas) CompX CSP2-634LPC (product) (Gas) CompX CSP4-1711LPC (vapor) (Gas)

EBW 77720102 (product) (Gas/E85) 77720202 (product) (Gas/E85) **EBW** 30430103 (vapor) (Gas/E85) **EBW EBW** 30420006 (vapor) (Gas/E85)

Pressure/Vacuum Vent Valve

FFS PV-Zero 407215901 (Gas/E85)

Husky 5885 (Gas/E85) OPW 723V (Gas/E85)

FFS Defender Series 804 (Gas/E85) VST VST-EVRPV-100 (Gas/E85) VST-EVRPV-200 (Gas/E85) VST

Note: VST-EVRPV-100 and VST-EVRPV-200 (with Test-In-Place

feature) both require installation of rain cap VST-RC-200.

In-Line

Pressure/Vacuum Vent

Vault

FFS DPVV (optional)

Tank Gauge Port Components

Veeder-Root 312020-952 (cap and adaptor kit) (Gas/E85)

Morrison Brothers 305XPA1100AKEVR (cap and adaptor kit) (Gas/E85) 305-0200AAEVR (replacement adaptor) (Gas/E85) Morrison Brothers Morrison Brothers 305XP-110ACEVR (replacement cap) (Gas/E85)

EBW 90037-E (In Tank Probe Cap and Adapter Kit) (Gas/E85)

Drop Tube Overfill Prevention Device¹ Defender Series OPV 70859X9YZ (Gas/E85) Defender Series OPV 70869X9YZ (Gas/E85)

> Defender Series OPV legend: X = upper drop tube length: 1 = 5 feet

2 = 10 feet

Equipment Manufacturer/Model Number

Y = Tube compatibility:

0 = Gas

2 = Gas/E85

Z = lower drop tube length:

1 = 8 feet

2 = 10 feet

EBW 70849X1Y (Gas) EBW 70849X3Y (Gas/E85)

X represented by:

1 = 5 foot length upper drop tube section 2 = 10 foot length upper drop tube section

Y represented by:

1 = 8 foot length bottom thread on section drop tube 2 = 10 foot length bottom thread on section drop tube

Drop Tube¹ OPW 61-T (various lengths) (Gas)(Phil-Tite Series Spill Containers

only)

EBW 7822041X-2 (X = various lengths) (Gas) EBW 7822043X-2 (X = various lengths) (Gas/E85)

Riser Offset¹ Phil-Tite M-6050-X (x = various offsets) (Gas/E85)

Double Fill¹Phil Tite (configuration only) (Gas/E85)Tank RiserDefender (configuration only) (Gas/E85)

Configuration

Tank Bottom Protector¹ Phil-Tite TBP-3516-E (Gas/E85)

Emergency Vent Exhibit 5 (for below-grade vaulted tank configuration)

Fuel Lock¹ McGard FL1 – Stick Only Fuel Lock (125007) (Gas)

McGard FL2 – Stick/Sampling Fuel Lock (125008) (Gas)

Bladder Plug McGard PSI104 (Gas)

¹ If these components are installed or required by regulations of other agencies, only those components and model numbers specified above shall be installed or used.

Table 1Components Exempt from Identification Requirements


Component Name	Manufacturer	Model Number		
Drop Tube	OPW EBW EBW	61-T Straight Drop Tube (Gas) 7822041X-2 (X = various lengths) (Gas) 7822043X-2 (X = various lengths) (Gas/E85)		
Dust Caps	Morrison Brothers	323C-0100ACEVR (vapor)* (Gas/E85) 305C-0100ACEVR (product)* (Gas/E85)		
	Veeder-Root	312020-952 (cap & adaptor) (Gas/E85)		
Tank Gauge Port Components	Morrison Brothers	305XPA1100AKEVR (cap and adaptor kit) (Gas/E85) 305-0200AAEVR (replacement adaptor) (Gas/E85) 305XP-1100ACEVR (replacement cap) (Gas/E85)		
	EBW	90037-E (In Tank Probe Cap and Adaptor Kit) (Gas/E85)		
Riser Adaptor	Phil-Tite	M/F 4X4 (Gas/E85) M/F 4X4-R (Gas/E85)		
Riser Offset	Phil-Tite	M-6050-X (X = various offsets) (Gas/E85)		
Riser Support Bracket	Phil-Tite	M-1600 (Gas/E85)		
Spill Container Lid	Phil-Tite EBW	85011 (Gas/E85) 7054401X (Gas/E85)		
Sump/Sump Lids	Varies	Varies (Gas/E85)		
Drop Tube Riser Clamp	FFS	70550901EC (Gas/E85)		
Replacement Drain Valve	EBW	EBW 70533729 EBW 70533719		
Drain Valve Blank Kit	EBW	90022		
Fuel Lock	McGard	FL1, FL2		
Rain Cap	VST	VST-RC-200		

^{*} Morrison Brothers dust caps identified as 323C EVR and 305C EVR respectively.

The component in Table 2 may not be installed as a new or replacement part on or after September 1, 2002. This component, if installed prior to September 1, 2002, may be used for the remainder of it's useful life.

Table 2

Component Name	Manufacturer	Model Number
Drop Tube	Emco Wheaton	A0020 (various lengths) (Gas)





Phil-Tite Model 85000 Series Spill Containers




Defender 705 Series Spill Containerdouble wall (Gas/E85 Compatible)



Defender 705 Series Spill Containersingle wall (Gas/E85 Compatible)



(New Tag Front) Defender Series Spill Container (Gas/E85 Compatible)



(New Tag Back) Defender Series Spill Container (Gas/E85 Compatible)








Spill Container EBW 7XX-49Y-0Z





Phil-Tite Model SWF-100-B Product Adaptor





Phil-Tite Model SWV-101-B Vapor Adaptor





Phil-Tite SWF-100-SS Fill Adaptor





Phil-Tite SWF-101-SS Fill Adaptor


FFS PV-Zero P/V Vent Valve (Gas/E85) (Model and Serial Number on White Tag)



OPW 723V P/V Vent Valve (Gas/E85)



Husky 5885 P/V Vent Valve (Gas/E85) (Husky Name on Bottom Flange)



FFS 804 P/V Vent Valve (Gas/E85)



Defender Series In-Line Vault (optional)







EBW Model 70849X1Y Overfill Prevention Device (Gas Compatible)




EBW 70849X3Y Autolimiter (Gas/E85 Compatible)



Defender OPV series 70859X9YZ (Gas/E85 compatible)



Defender OPV series 70869X9YZ (Gas/E85 compatible) Kiwa Label



OPW 634-TT-EVR Product Dust Cap (Gas/E85 Compatible)

OPW 1711-T-EVR Vapor Dust Cap (Gas/E85 Compatible)



OPW 634LPC Product Dust Cap (Gas Compatible)



OPW 1711LPC Vapor Dust Cap (Gas Compatible)



EBW 77720102 Product Dust Cap (Gas/E85)



EBW 30430103 Vapor Dust Cap (Gas/E85)



EBW 77720202 Product Dust Cap (Gas/E85 Compatible)



EBW 30420006 Vapor Dust Cap (Gas/E85)


Component Identification



Morrison Brothers 323C EVR Vapor Dust Cap (Gas/E85 Compatible)



Morrison Brothers 305C EVR Product Dust Cap (Gas/E85 Compatible)



Phil-Tite TBP-3516-E (Gas/E85) Series Tank Bottom Protector



CompX CSP1-634LPC Product Dust Cap



CompX CSP3-1711LPC Vapor Dust Cap (Gas Only)



CompX Tank Commander Lid Locks onto CSP1-634LPC and CSP3-1711LPC Dust Caps



CompX CSP2-634LPC Product Dust Cap



CompX CSP4-1711LPC Vapor Dust Cap (Gas Only)



CompX Tank Commander Lid Locks onto CSP2-634LPC and CSP4-1711LPC Dust Caps



McGard Fuel Lock Installation Position¹



McGard Fuel Lock (FL1 on Left, FL2 on Right)

22

¹Optional component, but if installed this picture shows the correct installation location in the pipe just below the Product Rotatable Adaptor in the drop tube.





VST VST-EVRPV-100 PV Valve

VST VST-EVRPV-200 PV Valve (w/ Test-In-Place)

Note: Valves do not show -100 or -200, just VST-EVRPV and unique serial number.



VST VST-RC-200 Rain Cap

Exhibit 2 VR-101 Revision X

Installation, Maintenance and Compliance Specifications

This Exhibit contains the installation, maintenance and compliance standards and specifications applicable to the Franklin Fueling System (FFS) Phase I system installed in a gasoline dispensing facility (GDF). Table 2-1 summarizes the compliance standard and specification with the corresponding test method. Table 2-2 describes the maintenance interval for the FFS Phase I System components.

General Specifications

- 1. Typical installations of the FFS Phase I system and system components are shown in Figures 2A through 2N.
- 2. The FFS Phase I system shall be installed, operated and maintained in accordance with the CARB Approved Installation, Operation and Maintenance Manual for the Franklin Fueling Systems, Inc. Phil-Tite/EBW/FFS Phase I Vapor Recovery System.
- 3. Any repair or replacement of system components shall be done in accordance with the CARB Approved Installation, Operation and Maintenance Manual for the Franklin Fueling Systems, Inc. Phil-Tite/EBW/FFS Phase I Vapor Recovery System.
- 4. Unless otherwise specified in this Executive Order (EO), the FFS Phase I system shall comply with the applicable performance standards and performance specifications in CP-201.
- 5. Installation, maintenance and repair of system components, including removal and installation of such components in the course of any required tests, shall be performed by FFS certified technicians. Additional certifications may be required in accordance with District requirements.

Pressure/Vacuum Vent Valves For Storage Tank Vent Pipes

- 1. No more than three certified pressure/vacuum vent valves (P/V valves) listed in Exhibit 1 shall be installed on any GDF underground storage tank system.
- 2. Compliance determination of the following P/V valve performance specifications shall be at the option of the districts:
 - a. The leak rate of each P/V valve shall not exceed 0.05 cubic feet per hour (CFH) at 2.00 inches of H₂O positive pressure and 0.21 CFH at -4.00 inches of H₂O negative pressure as determined by TP-201.1E, Leak Rate and Cracking Pressure of Pressure/Vacuum Vent Valves (October 8, 2003).
 - b. The positive pressure setting is 2.5 to 6.0 inches of H₂O and the negative pressure setting is 6.0 to 10.0 inches of H₂O as determined by TP-201.1E, Leak Rate and Cracking Pressure of Pressure/Vacuum Vent Valves (October 8, 2003).
- 3. Compliance determination of the P/V valve performance specifications in items 2a and 2b for the FFS PV-Zero P/V vent valve shall be conducted with the valve remaining in its installed position on the vent line(s). The PV-Zero portion of the CARB-Approved Installation, Operation

- and Maintenance Manual for the Franklin Fueling Systems Phil-Tite/EBW/FFS) Phase I Vapor Recovery System outlines the equipment needed to test the valve in its installed position.
- 4. A manifold may be installed on the vent pipes to reduce the number of potential leak sources and P/V valves installed. Vent pipe manifolds shall be constructed of steel pipe or an equivalent material that has been listed for use with gasoline. If a material other than steel is used, the GDF operator shall make available information demonstrating that the material is compatible for use with gasoline. One example of a typical vent pipe manifold is shown in Figure 2F. This shows only one typical configuration; other manifold configurations may be used. For example, a tee may be located in a different position, or fewer pipes may be connected, or more than one P/V valve may be installed on the manifold.
- 5. Each P/V valve shall have permanently affixed to it a yellow, gold, or white colored label with black lettering stating the following specifications:

Positive pressure setting: 2.5 to 6.0 inches H₂O Negative pressure setting: 6.0 to 10.0 inches H₂O Positive Leakrate: 0.05 CFH at 2.0 inches H₂O Negative Leakrate: 0.21 CFH at -4.0 inches H₂O

- 6. When installing either the VST-EVRPV-100 or VST-EVRPV-200, the VST-RC-200 rain cap must be installed with it. If multiple VST-EVRPV valves are installed, it is permissible to manifold above the VST-EVRPV valves so only a single VST-RC-200 rain cap is installed.
- 7. Conducting TP-201.1E on the VST-EVRPV-200 PV valve can be performed with the VST Test In Place (TIP) device. This device isolates the PV vent being tested from the rest of the UST system to allow for PV testing without disturbing operations at the site. See Page 4 of the VST-EVRPV portion of the CARB-Approved Installation, Operation and Maintenance (IOM) manual for instructions.
- 8. The VST Test In Place (TIP) device may be used to isolate the VST-EVRPV-200 PV from the rest of the UST to perform other system pressure tests as needed. See Page 4 of the VST-EVRPV portion of the CARB-Approved Installation, Operation and Maintenance (IOM) manual for instructions.

Rotatable Product and Vapor Recovery Adaptors

- 1. Rotatable product and vapor recovery adaptors shall be capable of at least 360-degree rotation and have an average static torque not to exceed 108 inch-pounds (9 foot-pounds). Compliance with this requirement shall be demonstrated in accordance with TP-201.1B, Static Torque of Rotatable Phase I Adaptors (October 8, 2003).
- 2. The vapor adaptor poppet shall not leak when closed. Compliance with this requirement shall be verified by the use of commercial liquid leak detection solution, or by bagging, when the vapor containment space of the underground storage tank is subjected to a non-zero gauge pressure. (Note: leak detection solution will detect leaks only when positive gauge pressure exists.)

Vapor Recovery and Product Adaptor Dust Caps

Dust caps with intact gaskets shall be installed on all Phase I tank adaptors.

Spill Container Drain Valve

The spill container drain valve is configured to drain liquid directly into the drop tube and is isolated from the underground storage tank ullage space. The leak rate of the drain valve shall not exceed 0.17 CFH at 2.00 inches H₂O. Depending on the presence of the drop tube overfill prevention device, compliance with this requirement shall be demonstrated in accordance with either TP-201.1C, Leak Rate of Drop Tube/Drain Valve Assembly (July 12, 2021), or TP-201.1D, Leak Rate of Drop Tube Overfill Prevention Device and Spill Container Drain Valve (July 12, 2021).

Drop Tube Overfill Prevention Device

- The Drop Tube Overfill Prevention Device (overfill device) is designed to restrict the flow of
 gasoline delivered to the underground storage when liquid levels exceed a specified capacity.
 The drop tube overfill device is not a required component of the vapor recovery system, but may
 be installed as an optional component of the system. Other requirements may apply.
- 2. The leak rate of the overfill device shall not exceed 0.17 CFH at 2.00 inches H₂O when tested as in accordance with TP-201.1D, Leak Rate of Drop Tube Overfill Prevention Device and Spill Container Drain Valves (July 12, 2021).
- 3. The discharge opening of the fill pipe must be entirely submerged when the liquid level is six inches above the bottom of the tank as shown in Figures 2A and 2D.

Riser Adaptor

For "Phil-Tite" series spill container installations, the Riser Adaptor shall provide a machined surface on which a gasket can seal and ensures that the seal is not compromised by an improperly cut or improperly finished riser. A Threaded Riser adaptor shall be installed on the following required connections. As an option, the adaptor may be installed on other connections.

- a. Product Spill Container (required)
- b. Vapor Recovery Spill Container (required)
- c. Tank Gauging Components (required)

For "Defender Series" spill container installations, the Riser Adaptor should only be used with the NPSM (straight thread) base. The Riser Adaptor should not be used with the Defender Series Base with NPT (tapered thread) base. This is applicable for both the vapor and fill/product sides. Field conditions will dictate which base to use. If the existing riser is not cut square, those conditions will require the riser adaptor.

Vapor Recovery Riser Offset

- 1. The vapor recovery tank riser may be offset from the tank connection to the vapor recovery Spill Container provided that the maximum horizontal distance (offset distance) does not exceed twenty (20) inches. One example of an offset is shown in Figure 2E.
- A vapor recovery riser shall be offset up to 20 inches horizontal distance with use of commercially available, four (4) inch steel pipe fittings, a Phil-Tite Model M-6050 Vapor Riser Offset, or a combination of the two products. An example of a Phil-Tite Model M-6050 configuration is shown in Figure 2E.

Tank Gauge Port Components

The tank gauge adaptor and cap are paired. Therefore, an adaptor manufactured by one company shall be used only with a cap manufactured by the same company.

Warranty

Each manufacturer listed in Exhibit 1 shall include a warranty tag with the certified component(s). The manufacturer warranty tag, included with each component, shall be provided to the service station owner/operator at the time of installation.

Connections and Fittings

All connections and fittings not specifically certified with an allowable leak rate shall not leak. The absence of vapor leaks shall be verified with the use of commercial liquid leak detection solution (LDS), or by bagging, when the vapor containment space of the underground storage tank is subjected to a non-zero gauge pressure. (Note: leak detection solution will detect leaks only when positive gauge pressure exists).

Double Fill Configuration

A Defender and or Phil-Tite Double Fill Configuration shall be allowed for installation provided that no more than two fill points are installed on any single underground storage tank and that no offset of the vapor recovery riser pipe is installed. An example of this configuration is shown in Figure 2C.

Maintenance Records

Each GDF operator or owner shall keep records of maintenance performed at the facility. Such record shall be maintained on site or in accordance with district requirements or policies. Additional information may be required in accordance with district requirements or policies. The records shall include the maintenance or test date, repair date to correct test failure, maintenance or test performed, affiliation, telephone number, name and Certified Technician Number of individual conducting maintenance or test. An example of a Phase I Maintenance Record is shown in Figure 20.

Table 2-1
Gasoline Dispensing Facility Compliance Standards and Specifications

A. Component / System	Test Method	a) Standard or Specification
Rotatable Phase I Adaptors	TP-201.1B	Minimum, 360-degree rotation Maximum, 108 pound-inch average static torque
Overfill Prevention Device	TP-201.1D	}0.17 CFH at 2.00 inches H₂O
Spill Container Drain Valve	TP-201.1C or TP-201.1D	}0.17 CFH at 2.00 inches H₂O
P/V Valve ¹	TP-201.1E	Positive pressure setting: 2.5 to 6.0 inches H ₂ O Negative pressure setting: 6.0 to 10.0 inches H ₂ O Positive Leakrate: 0.05 CFH at 2.0 inches H ₂ O Negative Leakrate: 0.21 CFH at -4.0 inches H ₂ O
Vapor Recovery System	TP-201.3	As specified in TP-201.3 and/or CP-201
Connections and fittings certified without an allowable leak rate	Leak Detection Solution or bagging	No leaks

5


¹ Compliance determination is at the option of the district.

Table 2-2
Maintenance Intervals for System Components²

Manufacturer	Component	Maintenance Interval
All Models	Dust Caps	Annual
All Models	In Tank Gauge Port Probe Cap and Adaptor Kit	Annual
FFS	Drop Tube Overfill Prevention Device 70849X1Y series Drop Tube Overfill Prevention Device 70849X3Y series Drop Tube Overfill Prevention Device 70859X9YZ series Drop Tube Overfill Prevention Device 70869X9YZ series	Annual
FFS	782 Straight Drop Tube	Annual
Husky	Pressure/Vacuum Vent Valve	Annual
FFS	Pressure/Vacuum Vent Valve	Annual
OPW	Pressure/Vacuum Vent Valve	Annual
OPW	61-T Straight Drop Tube	Annual
FFS	Spill Container (all models)	Every 3 years
FFS	SWF-100-B Product Adaptor SWF-100-SS Product Adaptor	Annual
FFS	SWV-101-B Vapor Adaptor SWV-101-SS Vapor Adaptor	Annual


² Maintenance must be conducted within the interval specified from the date of installation and at least within the specified interval thereafter.


Figure 2A
Typical Product Side Installation of Phil-Tite System Using EBW Autolimiter II 70849X Series
(Defender OPV series 70859X9YZ, 70869X9YZ alternate component)³



³ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.


Figure 2B
Alternate Phil-Tite Sump Configuration⁴





⁴ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.


Figure 2C
Typical Defender/Phil-Tite Double Fill Configuration



9


Figure 2D

Typical Product Installation of Defender Series Spill Container Using Defender OPV series 70859X9YZ, 70869X9YZ(EBW Autolimiter II 70849X Series optional)⁵



⁵ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.


Figure 2E
Typical Phil-Tite Model M-6050 Vapor Recovery Riser Offset



Note: These figures represent instances where a vapor recovery riser has been offset in order to construct a two-point Phase I vapor recovery system. The figure on the right illustrates an offset using a 90-degree elbow. However, in some instances, elbows less than 90 degrees may be used. All fittings and pipe nipples shall be 4-inch diameter similar to those of the spill container and rotatable Phase I adaptors in order to reduce back pressure during a gasoline delivery.


11

Figure 2F
Typical Vent Pipe Manifold




Note: This shows one typical configuration; other manifold configurations may be used. For Example, a tee may be located in a different position, or fewer pipes may be connected, or more than one P/V valve may be installed on the manifold

Figure 2G
Typical Product Side Installation of Defender Series Spill Container: Single Wall Direct
Bury Configuration⁶



⁶ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.

Figure 2H
Typical Product Side Installation of Defender Series Spill Container: Double Wall Direct
Bury Configuration with I² Monitor⁷




⁷ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.

Figure 2I

Typical Product Side Installation of Defender Series Spill Container: Double Wall Direct

Bury Configuration with TSP-ULS Liquid Sensor⁸



⁸ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.

Figure 2J
Typical Vapor Recovery Side Installation of Defender Series Spill Container Single Wall Direct
Bury Configuration




Figure 2K
Typical Vapor Recovery Side Installation of Defender Series Spill Container Double Wall Direct
Bury Configuration with I² Monitor




Figure 2L

Typical Vapor Recovery Side Installation of Defender Series Spill Container Double Wall Direct

Bury Configuration with TSP-ULS Liquid Sensor





Figure 2M
Typical Product Side Installation using EBW system
(Defender OPV series 70859X9YZ, 70869X9YZ optional)9



-

⁹ McGard FL1 or FL2 Fuel lock (Optional- Not Pictured), if installed, would be positioned inside the riser seal (or pipe nipple) below the rotatable adaptor.

Figure 2N
Typical Vapor Recovery Installation using EBW system




Figure 20
Example of a GDF Phase I Maintenance Record

Date of Maintenance/ Test/Inspection/ Failure	Repair Date to Correct Test Failure	Maintenance/Test/Inspection Performed and Outcome	Affiliation	Name and Certification Technician Number of Individual Conducting Maintenance or Test(s)	Telephone Number

EXHIBIT 3 VR-101 Revision X

Manufacturing Performance Standards and Specifications

The Franklin Fueling Systems system and all components shall be manufactured in compliance with the performance standards and specifications in CP-201, as well as the requirements specified in this Executive Order. All components shall be manufactured as certified; no change to the equipment, parts, design, materials or manufacturing process shall be made unless approved in writing by the Executive Officer or his delegate. Unless specified in Exhibit 2 or in the CCARB approved Installation, Operation and Maintenance Manual for the Phil-Tite/EBW/FFS Phase I Vapor Recovery System, the requirements of this section apply to the manufacturing process and are not appropriate for determining the compliance status of a GDF.

Pressure/Vacuum Vent Valves for Storage Tank Vent Pipes

- 1. Each Pressure/Vacuum Vent Valve (P/V valve) shall be performance tested at the factory for cracking pressure and leak rate at each specified pressure setting and shall be done in accordance with TP-201.1E, Leak Rate and Cracking Pressure of Pressure/Vacuum Vent Valves (October 8, 2003).
- Each P/V valve shall be shipped with a card or label stating the performance specifications listed in Table 3-1, and a statement that the valve was tested to, and met, these specifications.
- 3. Each P/V valve shall have permanently affixed to it a yellow, gold, or white colored label with black lettering listing the positive and negative pressure settings and leak rate standards listed in Table 3-1. The lettering of the positive and negative pressure settings and leak rate standards on the label shall have a minimum font size of 20.

Rotatable Product and Vapor Recovery Adaptors

- 1. The rotatable product and vapor recovery adaptors shall not leak.
- 2. The product adaptor cam and groove shall be manufactured in accordance with the cam and groove specifications shown in Figure 3A of CP-201.
- 3. The vapor recovery adaptor cam and groove shall be manufactured in accordance with the cam and groove specifications shown in Figure 3B of CP-201.
- 4. Each product and vapor recovery adaptor shall be tested at the factory to, and met, the specifications listed in Table 3-1 and shall have affixed to it a card or label listing these performance specifications and a statement that the adaptor was tested to, and met such specifications.

Spill Container and Drain Valves

Each Spill Container Drain Valve shall be tested at the factory to, and met, the specification listed in Table 3-1 and shall have affixed to it a card or label listing the performance specification and a statement that the valve was tested to, and met, such performance specification.

Drop Tube Overfill Prevention Device

Each Drop Tube Overfill Prevention Device shall be tested at the factory to, and met, the specification listed in Table 3-1 and shall have affixed to it a card or label listing the performance specification and a statement that the device was tested to, and met, such performance specification.

Table 3-1

Manufacturing Component Standards and Specifications

A. Component	Test Method	Standard or Specification
Rotatable Phase I Adaptors	TP-201.1B	Minimum, 360-degree rotation Maximum, 108 pound-inch average static torque
Rotatable Phase I Adaptors	Micrometer	Cam and Groove Specifications (CP-201)
Overfill Prevention Device	TP-201.1D	0.17 CFH at 2.00 inches H₂O
Spill Container Drain Valve	TP-201.1C or TP-201.1D	}0.17 CFH at 2.00 inches H₂O
Pressure/Vacuum Vent Valve	TP-201.1E	Positive Pressure: 2.5 to 6.0 inches H ₂ O Negative Pressure: 6.0 to 10.0 inches H ₂ O Leak rate: \$\} 0.05 CFH at +2.0 inches H ₂ O \$\} 0.21 CFH at -4.0 inches H ₂ O

EXHIBIT 4 VR-101 REVISION X

Manufacturer Warranties

This exhibit includes the manufacturer warranties for all components listed in Exhibit 1, including replacement parts and subparts. The manufacturer warranty tag, included with each component, shall be provided to the service station owner/operator at the time of installation.

Franklin Fueling Systems Warranty Statement and Tag

Franklin Fueling Systems (FFS) Enhanced Vapor Recovery (EVR) products are offered for sale under the brand names of Healy, INCON, Phil-Tite, EBW, and Franklin Fueling Systems (collectively referred to as "FFS EVR products"). FFS EVR products are fully tested at the time of manufacture to meet the applicable performance standards and specifications to which it was certified by the California Air Resource Board (CCARB) for the duration of the warranty period, as indicated in the related CCARB Executive Order (EO). Performance standards and specifications are listed in Exhibit 2 (System/Compliance Specifications) and Exhibit 3 (Manufacturing Performance Standards) in the related CCARB EO.

FFS warrants that FFS EVR products installed in California will conform to the warranty terms and conditions required by the California Certification Procedure for Vapor Recovery Systems at Gasoline Dispensing Facilities (CP-201) with respect to (a) transferability of warranties for FFS EVR products, (b) design changes to FFS EVR products, (c) performance specifications of the FFS EVR products, and (d) duration of the warranty period of FFS EVR products.

FFS EVR products are warranted to the initial purchaser, and any subsequent purchaser within the warranty period, for workmanship, performance, and materials when properly installed, used and maintained in accordance with the CCARB Approved Installation, Operation, and Maintenance Manuals by certified technicians or an owner/operator as defined in the related CCARB EO and to generally accepted industry standards.

FFS reserves the right to make changes in the design or to make additions or improvements with respect to FFS EVR products without incurring any obligation to modify or install same on previously manufactured products, upon written approval from CCARB.

FFS reserves the right to change or cancel all or any part of this limited warranty, upon written approval from CCARB. Any such change or cancellation will be effective for products sold by FFS after the date of such change or cancellation. No agents, distributors, dealers, or employees of FFS are authorized to make modifications to this warranty or to make additional warranties with respect to any FFS EVR products. Accordingly, any statements made by individuals, whether oral or written, shall not constitute a warranty of FFS and shall not be relied upon.

FFS warrants the workmanship and materials of FFS EVR products to be free of defects, at the time of sale by FFS, for a period of one year (12 months) from the date of installation. When warranty for FFS EVR products cannot be verified to date of installation, claims will be honored for a period of fifteen (15) months from the date of purchase. When warranty for FFS EVR product cannot be verified to date of installation or date of purchase, claims will be honored for a period of eighteen (18) months from date of manufacture by FFS (for location of date of manufacture on components, see related CCARB EO Exhibit 1 – Equipment List). In all cases, installation date or purchase date will require providing formal documentation to FFS as

evidence of applicable warranty coverage or date of manufacture will be used to determine duration of warranty period. Formal documentation may include, but is not limited to, FFS authorized service company and distributor work orders, startup/installation documentation, maintenance logs, and/or sales receipts.

FFS shall not be liable for any loss or damage whatsoever, including, without limitation, loss in profits, loss in sales, loss of fuel or other products, loss of use of equipment, facilities or service, costs of environmental remediation, diminution in property value, or any other special, incidental or consequential damages of any type or nature, and all such losses or damages are hereby disclaimed and excluded from this limited warranty.

Use of non-FFS replacement parts, the unauthorized addition of non-FFS items to FFS EVR products, and the unauthorized alteration of FFS EVR products will void warranty. FFS shall, as to each defect, be relieved of all obligations and liabilities under a components warranty if the FFS EVR products have been operated with any accessory, equipment, or a part not specifically approved by FFS and not manufactured by FFS to FFS design and specifications.

FFS EVR product warranty shall not apply to any products which have been mishandled, incorrectly installed or applied, altered in any way, which has been repaired by any party other than qualified technicians, or when such failure is due to misuse or conditions of use (such as, but not limited to, blown fuses, sheared breakaway screws, corrosion damage, negligence, accidents, or normal wear of plastic/rubber parts including scuff guards and seals). FFS EVR product warranty shall not apply to acts of terrorism, acts of war, or acts of God (such as, but not limited to, fire, flood, earthquake, or explosion). Unless otherwise expressly provided in a specific FFS written warranty, FFS does not provide coverage for labor or shipping charges, shall not be liable for any costs or charges attributable to any product testing, maintenance, installation, repair or removal, or any tools, supplies, or equipment need to install, repair, or remove any FFS EVR product.

Other than those FFS EVR products specifically designated for fuel concentrations of 85% ethanol with 15% gasoline (E85), FFS EVR product warranty shall not cover any components that have been in contact with fuel concentrations greater than 15% ethanol or 15% methanol by volume (up to E15/M15).

Claims for FFS EVR product warranty must be submitted in writing promptly after discovery of a defect with a Returned Goods Authorization (RGA) Number from FFS. FFS will honor warranty claims processed through FFS authorized service companies and distributors only. FFS will honor warranty claims submitted no more than thirty (30) days after the end of the applicable warranty period. Product returned for warranty inspection must be shipped freight prepaid to FFS's facilities, with the RGA Number indicated on the returned product, to the following address for inspection:

INCON branded products: Franklin Fueling Systems, Inc. ATTN: Warranty Department 34 Spring Hill Road Saco, ME 04072 USA All other FFS EVR Products: Franklin Fueling Systems, Inc. ATTN: Warranty Department 3760 Marsh Road Madison, WI 53718 USA

Franklin Fueling Systems, upon inspection and after determination of a warranty defect, will at its option, repair or replace defective parts returned to FFS's facility or where the product is in use. Repaired or replaced parts will be returned freight prepaid by FFS

A copy of this limited warranty is to be retained with the equipment, on-site with the facility owner/operator.
Component Model Number :
Component Date of Manufacturer :
Component Install Date :
Facility Name :
Facility Address :
Installer Name :
Installer Signature :

Morrison Bros. Co. Warranty Statement and Tag

WARRANTY— All Morrison products are thoroughly tested before shipment and meet all applicable performance standards and specifications of related ARB executive orders and vapor recovery procedures of CP-206 (Certification Procedure for Vapor Recovery Systems at Gasoline Dispensing Facilities Using Aboveground Storage Tanks) or CP-201 (Certification Procedure for Vapor Recovery Systems at Dispensing Facilities). This warranty shall include the ongoing compliance with all applicable performance standards and specifications for the duration of the warranty. Only material found to be defective in manufacture will be repaired or replaced. Claims must be made within one year from the date of installation, and Morrison Bros. Co. will not allow claims for labor or consequential damage resulting from purchase, installation or misapplication of the product. This warranty will include the initial purchaser and any subsequent purchasers of the initial equipment within the warranty period. This warranty registration must remain with the equipment and be provided to the end user. If a warranty claim needs to be pursued, a copy of this information and the invoice of these products to the purchaser must be supplied to Morrison for verification.

Installation Date:				
Name Of Installer/Contractor				
Installation Company: Name				_
Address				_
City	State	Zip		
Business At Installation Site: N	ame			
Address				
City	State	Zip		
Morrison Product(s) I.D Number	ers With Da	te Of Manufacture		
. ,				

Date of manufacture can be found on the product identification label applied to the finished product. This warranty registration must remain with the equipment and be provided to the end user. If a warranty claim needs to be pursued, a copy of this information and the invoice of these products to the purchaser must be supplied to Morrison for verification.

OPW STANDARD PRODUCT WARRANTY TAG

Notice: FlexWorks by OPW, Inc., VAPORSAVER™ and all other OPW products must be used in compliance with all applicable federal, state, provincial and local laws, rules and regulations. Product selection is the sole responsibility of the customer and/or its agents and must be based on physical specifications and limitations, compatibility with the environment and material to be handled. All illustrations and specifications in this literature are based on the latest production information available at the time of publication. Prices, materials and specifications are subject to change at any time, and models may be discontinued at any time, in either case, without notice or obligation.

OPW warrants solely to its customer (the initial purchaser and any subsequent purchasers within the warranty period) that the following products sold by OPW will be free from defects in materials and workmanship under normal use and conditions for the periods indicated:

PRODUCT	WARRANTY PERIOD			
FlexWorks Primary Pipe	10 years from date of manufacture			
All Products and replacement parts installed in the State of California Certified to California CP-201 and/or CP-206 Standards*	1 year from date of installation (proof of purchase from certified contractors/technicians required) OPW warrants ongoing compliance with the standards and specifications for the duration of the warranty period required by the State of California; this limited warranty is under the condition the equipment was installed and maintained by trained and certified contractors/technicians unless noted in Installation Manual			
All other Products and replacement parts	1 year from date of manufacture**			
*Products certified to California CP-201 and/or CP-206 Standards have been factory tested and met all applicable performance standards and specifications and will have an OPW registration card enclosed/attached to the product				

OPW's exclusive obligation under this limited warranty is, at its option, to repair, replace or issue credit (in an amount not to exceed the list price for the product) for future orders for any product that may prove defective within the applicable warranty period. (Parts repaired or replaced under warranty are subject to prorated warranty coverage for remainder of the original warranty period). Complete and proper warranty claim documentation and proof of purchase required. All warranty claims must be made in writing and delivered during the applicable warranty period to OPW at OPW 9393 Princeton-Glendale Road Hamilton, Ohio, USA 45011, Attention: Customer Service Manager. No products may be returned to OPW without its prior written authority. This limited warranty shall not apply to any FlexWorks or VAPORSAVER™ product unless it is installed by an OPW attested installer and all required site and warranty registration forms are completed and received by OPW within 60 days of installation. This limited warranty also shall not apply to any FlexWorks, VAPORSAVER™ or other OPW product: unless all piping connections are installed with a nationally-recognized or state-approved leak detection device in each tank and dispenser sump (which are not for storage and from which all discharge hydrocCARBons must be removed, and the systems completely cleaned, within 24 hours); unless testable sumps utilize FlexWorks pipe and access fittings; unless a sump inspection log or an EPA recommended/required checklist is maintained and the results are furnished to OPW upon request; and unless OPW is notified within 24 hours of any known or suspected product failure and is provided with unrestricted access to the product and the site. This limited warranty also shall not apply to any product which has been altered in any way, which has been repaired by anyone other than a service representative authorized by OPW, or when failure or defect is due to: improper installation or maintenance (including, without limitation, failure to follow FlexWorks Quick Reference Manual Installation Guide and all product warning labels); abuse or misuse; violation of health or safety requirements; use of another manufacturer's, or otherwise unauthorized, substances or components; soil or other surface or subsurface conditions; or fire. flood, storm, lightning, earthquake, accident or any other conditions, events or circumstances beyond OPW's control.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ALL OTHER WARRANTIES INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXCLUDED.

OPW shall have no other liability whatsoever, whether based on breach of contract, negligence, gross negligence, strict liability or any other claim, including, without limitation, for special, incidental, consequential or exemplary damages or for the cost of labor, freight, excavation, clean-up, downtime, removal, reinstallation, loss of profit, or any other cost or charges. No person or entity is authorized to assume on behalf of OPW any liability beyond this limited warranty. This limited warranty is not assignable.

** Date of manufacture on this product is located (location will be specific to each component)



North America Toll Free - TELEPHONE: (800) 422-2525 - Fax: (800) 421-3297 - Email: domesticsales@opw-fc.com

9393 Princeton-Glendale Road Hamilton, Ohio 45011 International – TELEPHONE: (513) 870-3315 or (513) 870-3261 - Fax: (513) 870-3157 - Email: intlsales@opw-fc.com www.opwglobal.com

Comp X TANK Commander Warranty Statement and Tag

Seller warrants to the initial and subsequent purchasers, for a period of one year from date of installation, that the Products sold hereunder will, at the time of delivery: (a) comply with the CARB CP-201 standards and specifications for the duration of the warranty period for such Products in effect at the time of shipment or such other specifications as are expressly agreed upon by Seller and Buyer in writing; (b) be adequately contained, packaged, and labeled; and (c) conform to any promises and affirmations of fact made on the container and label. In the event that any such Products fail to conform to the foregoing warranty, Seller will, at its option, repair or replace such nonconforming Products, or credit Buyer for an amount not to exceed the original sales price of such Products. Shipping costs incurred in returning such nonconforming Products to Seller shall be borne by Seller, but Seller shall in no event be liable for any inspection, handling, or packaging costs incurred by Buyer in connection with such Products. Buyer's negligence, misuse, improper installation, or unauthorized repair or alteration, shall void this warranty. The TANK Commander Warranty tag is located on the inside cover of the product.

/ <u>vv</u>	<u>arranty i ag</u>
TANK Command	er TC-1
1 year warranty f	rom date of installation
Date of manufact	ture//
The Course V TAN	V O

The CompX TANK Commander product was factory tested and meets the standards and specifications to which it was certified by the California Air Resources Board (CCARB) as indicated in the related CCARB Phase I EVR Executive Orders.

Husky Corporation Warranty Statement and Tag

VAPOR PRODUCTS – Husky Corporation will, at its option, repair, replace, or credit the purchase price of any Husky manufactured product which proves upon examination by Husky, to be defective in material and/or workmanship for a period of one (1) year of installation or fifteen (15) months from the manufacture date of shipment by Husky, whichever occurs first. The warranty period on repaired or replacement vapor recovery products is only for the remainder of the warranty period of the defective product.

EVR PRODUCTS – With respect to EVR products installed in California, for a period of one (1) year from the date of installation, Husky warrants that the product will be free from defects in materials and workmanship (if the installation date is in question or indeterminable, Husky will warrant the product for 12 months from sale by Husky). Husky confirms that the warranty is transferable to a subsequent purchaser within the warranty period. However, the warranty does not follow the product from its initial installation location to succeeding locations. Husky confirms these products are warranted to meet the performance standards and specifications to which it was certified by CCARB for the duration of the warranty. EVR products must be installed per CCARB Executive Order and must follow the Husky Installation Instructions or the warranty is void. The warranty tag included with the EVR product must be provided to the end user at installation. A completed warranty tag and installation documentation is required to be returned with the product to be eligible for warranty consideration.

CONVENTIONAL PRODUCTS – Husky Corporation will, at its option, repair, replace, or credit the purchase price of any Husky manufactured product which proves upon examination by Husky, to be defective in material and/or workmanship for a period of one (1) year from the manufacture date of shipment by Husky.

Buyer must return the products to Husky, transportation charges prepaid. This Warranty excludes the replaceable bellows, bellows spring assembly, spout assembly and scuff guard, unless (i) damage is obvious when the product is removed from shipping carton and (ii) the defective product is returned to Husky prior to use. This warranty does not apply to equipment or parts which have been installed improperly, damaged by misuse, improper operation or maintenance, or which are altered or repaired in any way.

The warranty provisions contained herein apply only to original purchasers who use the equipment for commercial or industrial purposes. There are no other warranties of merchantability, fitness for a particular purpose, or otherwise, and any other such warranties are hereby specifically disclaimed.

Husky assumes no liability for labor charges or other costs incurred by Buyer incidental to the service, adjustment, repair, return, removal or replacement of products. Husky assumes no liability for any incidental, consequential, or other damages under any warranty, express or implied, and all such liability is hereby expressly excluded.

Husky reserves the right to change or improve the design of any Husky fuel dispensing equipment without assuming any obligations to modify any fuel dispensing equipment previously manufactured.



***** WARRANTY TAG

Husky Corporation 2325 Husky Way Pacific, Mo 63069

	(800) 325-3558			
	Station Name:			
	Store #: Date:	Model #:		
(\circ)	City: State:	Serial #:		
	Service Contractor:	Installation Date:		
	Service Tech:	Manufacturer Lot #:		
	Distributor:	Work order # (if applicable):		
	No warranty accepted without warranty tag filled out completely and attached to product.	RGA #:		
	completely and attached to product.	Form #009179-6 03/2013		

Husky General Fueling Products:

FOR REFERENCE ONLY

Reason for Return (check all applicable):				
Lever				
Notes / Comments:				

BACK VIEW

Veeder-Root Warranty Statement and Tag

This warranty applies only when the product is installed in accordance with Veeder-Root's specifications. This warranty will not apply to any product which has been subjected to misuse, negligence, accidents, systems that are misapplied or are not installed per Veeder-Root specifications, modified or repaired by unauthorized persons, or damage related to acts of God. Veeder-Root is not liable for incidental, consequential, or indirect damages or loss, including, without limitation, personal injury, death, property damage, environmental damages, cost of labor, clean-up, downtime, installation and removal, product damages, loss of product, or loss of revenue or profits. This warranty applies to the initial purchaser and any subsequent purchaser for the duration of the warranty period. THE WARRANTY CONTAINED HEREIN IS EXCLUSIVE AND THERE ARE NO OTHER EXPRESS, IMPLIED, OR STATUTORY WARRANTIES. WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED. CAP AND RING ADAPTOR

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation. During the warranty period, we or our representative will repair or replace the product, if determined by us to be defective, at the location where the product is in use and at no charge to the purchaser.

Warranty Card Language

EQUIPMENT WARRANTY

Veeder-Root warrants that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from date of installation.

Date of manufacture:

This component was tested at the time of manufacture and meets all the applicable performance standards and specification to which it was certified: EO VR-101 and EO VR-102.

For detailed warranty terms see EO VR101 or EO VR-102 warranty exhibits on the CARB Web site at http://www.CARB.ca.gov/vapor/eo-evrphasel.htm

McGard Warranty Statement and Tag

McGard Fuel Locks are fully tested at the time of manufacture to meet the applicable performance standards and specifications to which it was certified by the California Air Resource Board (CCARB) for the duration of the warranty period, as indicated in the related CCARB Executive Order (EO). Performance standards and specifications are listed in Exhibit 2 (System/Compliance Specifications) and Exhibit 3 (Manufacturing Performance Standards) in the related CCARB EO.

McGard warrants that McGard Fuel Lock products installed in California will conform to the warranty terms and conditions required by the California Certification Procedure for Vapor Recovery Systems at Gasoline Dispensing Facilities (CP-201) with respect to (a) transferability of warranties for McGard Fuel Locks, (b) design changes to McGard Fuel Locks, (c) performance specifications of the McGard Fuel Locks, and (d) duration of the warranty period of McGard Fuel Locks.

McGard Fuel Locks are warranted to the initial purchaser, and any subsequent purchaser within the warranty period, for workmanship, performance, and materials when properly installed, used and maintained in accordance with the CCARB Approved Installation, Operation, and Maintenance Manuals by certified technicians as defined in the related CCARB EO and to generally accepted industry standards.

McGard reserves the right to make changes in the design or to make additions or improvements with respect to McGard Fuel Locks without incurring any obligation to modify or install same on previously manufactured products, upon written approval from CCARB.

McGard reserves the right to change or cancel all or any part of this limited warranty, upon written approval from CCARB. Any such change or cancellation will be effective for products sold by McGard after the date of such change or cancellation. No agents, distributors, dealers, or employees of McGard are authorized to make modifications to this warranty or to make additional warranties with respect to any McGard Fuel Locks. Accordingly, any statements made by individuals, whether oral or written, shall not constitute a warranty of McGard and shall not be relied upon.

McGard warrants the workmanship and materials of McGard Fuel Locks to be free of defects, at the time of sale by McGard, for a period of one year (12 months) from the date of installation. When warranty for McGard Fuel Locks cannot be verified to date of installation, claims will be honored for a period of fifteen (15) months from the date of purchase. When warranty for McGard Fuel Locks cannot be verified to date of installation or date of purchase, claims will be honored for a period of eighteen (18) months from date of manufacture by McGard (date of manufacture is engraved on side of lock body). In all cases, installation date or purchase date will require providing formal documentation to McGard as evidence of applicable warranty coverage or date of manufacture will be used to determine duration of warranty period. Formal documentation may include, but is not limited to McGard authorized service company

and distributor work orders, startup/installation documentation, maintenance logs, and/or sales receipts.

McGard shall not be liable for any loss or damage whatsoever, including, without limitation, loss in profits, loss in sales, loss of fuel or other products, loss of use of equipment, facilities or service, costs of environmental remediation, diminution in property value, or any other special, incidental or consequential damages of any type or nature, and all such losses or damages are hereby disclaimed and excluded from this limited warranty.

Use of non-McGard replacement parts, the unauthorized addition of non-McGard items to McGard Fuel Locks, and the unauthorized alteration of McGard Fuel Locks will void warranty. McGard shall, as to each defect, be relieved of all obligations and liabilities under a components warranty if the McGard Fuel Locks have been operated with any accessory, equipment, or a part not specifically approved by McGard and not manufactured by McGard to McGard design and specifications.

McGard Fuel Lock warranty shall not apply to any products which have been mishandled, incorrectly installed or applied, altered in any way, which has been repaired by any party other than qualified technicians, or when such failure is due to misuse or conditions of use (such as, but not limited to, blown fuses, sheared breakaway screws, corrosion damage, negligence, accidents, or normal wear of plastic/rubber parts including scuff guards and seals). McGard Fuel Lock warranty shall not apply to vandalism, theft, acts of terrorism, acts of war, or acts of God (such as, but not limited to, fire, flood, earthquake, or explosion). Unless otherwise expressly provided in a specific McGard written warranty, McGard does not provide coverage for labor or shipping charges, shall not be liable for any costs or charges attributable to any product testing, maintenance, installation, repair or removal, or any tools, supplies, or equipment need to install, repair, or remove any McGard Fuel Lock.

Other than those McGard Fuel Locks specifically designated for fuel concentrations of 85% ethanol with 15% gasoline (E85), McGard Fuel Lock product warranty shall not cover any components that have been in contact with fuel concentrations greater than 15% ethanol or 15% methanol by volume (up to E15/M15).

Claims for McGard Fuel Lock warranty must be submitted in writing promptly after discovery of a defect with a Returned Goods Authorization (RGA) Number from McGard. McGard will honor warranty claims processed through McGard authorized service companies and distributors only. McGard will honor warranty claims submitted no more than thirty (30) days after the end of the applicable warranty period. Product returned for warranty inspection must be shipped freight prepaid to McGard's facilities, with the RGA Number indicated on the returned product, to the following address for inspection:

McGard LLC, ATTN: Warranty Department, 3875 California Road, Orchard Park, NY 14127 USA

McGard, upon inspection and after determination of a warranty defect, will at its option, repair or replace defective parts returned to McGard's facility or where the product is in use. Repaired or replaced parts will be returned freight prepaid by McGard.

A copy of this limited warranty is to be retained with the equipment, on-site with the f owner/operator.	acility
Component Model Number:	
Component Date of Manufacturer:	
Component Install Date:	
Facility Name:	
Facility Address:	
Installer Name:	_
Installer Signature:	-

CUSTOMER COPY

To be left at gasoline dispensing facility (GDF) at time of installation

Manufacturing Date:

(SEE BOX LABEL)

Serial Number: (Fill in at time of installation)

VST Warranty Statement

This limited warranty is given by Vapor Systems Technologies, Inc. (hereinafter VST) to the initial purchaser, and any subsequent purchasers of new equipment, within the warranty period of products manufactured by VST. VST products:

- Are factory tested and meet all applicable performance standards and specifications.
- Should be used in compliance with all applicable federal, state, and local laws and regulations to which they
 were certified.
- Are warranted to be free from defect in material and workmanship with ongoing compliance to all applicable
 performance standards and specifications under normal use, service, proper installation, inspections, and
 maintenance practices per manufacturer specifications.

VST warrants the materials and workmanship to be free from defects in accordance with the following provisions:

- 1. This warranty does not apply to any products that have:
 - Been subject to misuse, abuse, tampering, negligence, accident, or drive off.
 - Been misapplied, improperly installed, or not installed per VST's instructions and specifications.
 - Been modified, altered, rebuilt or repaired by unauthorized persons or outside the criteria of VST specifications.
 - Been improperly maintained and/or improperly inspected in accordance with the system's or product's periodic maintenance schedule, and any inspection and/or maintenance requirements imposed by the State or any government agency.
 - Been exposed to contact with fuels containing greater than 5% methanol, 10% ethanol, or 15% MTBE by volume or any exposure to M85/E85 fuel, unless the product is rated for that type of fuel.
 - Been subject to damage resulting from acts of God.
- 2. This warranty does not cover and VST is not responsible or liable for:
 - Incidental, consequential and/or indirect damages or loss including, but not limited to,personal injury, death, property damage, environmental damage, cost of labor, clean-up, downtime, installation and removal, product damage, and loss of product, revenue or profits.
 - Any claims or lawsuits against the purchaser and/or distributor.
 - Labor or materials necessary to disconnect or connect the warranted product for return to VST.

VST products used on systems that have not been listed by a nationally recognized testing laboratory (NRTL) or use that falls outside intended field of use voids all warranties.

The duration of this warranty is TWELVE (12) MONTHS from the time of installation provided timely valid proof of installation is submitted to VST. Valid proof of installation options include, but are not limited to:

 VST Product Warranty Registration Card is properly completed and returned to VST at time of installation and within (6) SIX MONTHS from the date of manufacture.

OR

- In lieu of a legitimate, completed and returned VST Product Warranty Registration Card within the first (6) SIX MONTHS from the date of manufacture, VST requires the following:
 - A completed gasoline dispensing facility (GDF) monthly maintenance log from the month in which the VST equipment was installed and documented, AND
 - 2. One of the following documents that may be used as a reference installation date:
 - A valid distributor invoice
 - A valid contractor invoice

The above options must be clearly marked with:

- All VST product serial numbers
- Product sale date and/or installation date
- Purchaser name, address, and phone number

If valid proof of installation is not received by VST, as noted above, the warranty period is TWELVE (12) MONTHS from the VST date of manufacture.

In the event of a warranty claim:

- The purchaser/distributor must obtain a copy of a Return Goods Authorization (RGA) from VST prior to returning
 product so as to ensure proper processing. All warranty claim returns must be shipped freight prepaid by the
 purchaser and/or distributor.
- Warranty status will be determined upon inspection at VST's facility within THIRTY (30) DAYS of receipt by VST of
 the warranted products. All returned merchandise deemed Not Under Warranty; will be held by VST for SEVEN
 (7) BUSINESS DAYS prior to disposal. Return of this product to the purchaser/distributor will require purchaser/
 distributor to issue a call tag within SEVEN
 (7) BUSINESS DAYS of notification.
- Repair or replacement of the warranted product is the EXCLUSIVE REMEDY under the terms of this warranty. No other warranty exists.

VST, as to each defect, shall be relieved of all obligations and liabilities under this Limited Warranty if the products have been operated with any accessory, equipment, or a part not specifically approved by VST and the appropriate governing regulatory agencies.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER WARRANTIES. VST MAKES NO OTHER WARRANTIES (WHETHER WRITTEN OR ORAL), EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE, AND ANY OTHER SUCH WARRANTIES ARE HEREBY DISCLAIMED.

VST NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON OR ENTITY TO ASSUME FOR IT OR BIND IT TO ANY OTHER LIABILITY OR OBLIGATION RELATED TO OR IN CONNECTION WITH THIS LIMITED WARRANTY.

VST reserves the right to make changes at any time to prices and designs or make additions or improvements with respect to its products, without incurring any obligation to modify or install same on previously manufactured products.

Page 6 9570-565 – 05/24

Warranty Registration Card:

- Cut Out
- Fill out completely
- Return to VST for Warranty Registration at time of

Product Return Tag:

- Cut Out
- Fill out completely when submitting a Warranty Return Claim
- Include completed form in box with Warranty Return Claim product
 • Include RGA paperwork

IMI PRODUI REGIST REGISTRATION See VST Warrar complete Warrar complete Warrar A copy of the Vs is included in every complete warrar and the Vs is included in every complete warrar and the Vs is included in every complete warrar and the Vs is included in every complete warrar and the Vs is included in every complete warrar and the Vs is included in every complete warrance was a complete was a complete warrance was a complete was a comp	ASC Company:
Phone: (937) 704-9333 • Fax: (937) 704-9443 IMPORTANT PRODUCT WARRANTY REGISTRATION CARD REGISTRATION CARD COMPLETELY) See VST Warranty Statement for complete Warranty Statement is included in every product carton. PRODUCT STYLE: PROCESSOR Phone: (937) 704-9443 WWWW.VSthose.com SERIAL NUMBER: INSTALLATION DATE: INSTALLATION SITE NAME: INSTALLATION SITE PHONE NUMBER: INSTALL	a warranty claim:
	This side of tag to be filled in by ASC

	Retu • Incl Clair	Out out co irn Cl ude c m pro	omplaim omp duct	etely w	orm in b		ng a Warranty th Warranty Return		Cut Out Fill out completely Return to VST for Warranty Registration at time of installation
.//	/				<i>,</i>				
No warranty accepted without tag filled out and attached to product.						ranty claim processing:		9573-001 02/22	
No warranty accepted v					RGA#:	below items for accurate warranty claim processing:	side of tag other side of tag) er to other side of tag) er to other side of tag)	Phone: 1-888-VST-HOSE 1-888-878-4673 Website: www.vsthose.com	
YET P/V Valve Return Tag	Distributor Name:	Street Address:	City, State & Zip:	Distributor Phone #:		Distributor should check off "all" of the belo	 □ RGA number is obtained and filled in on this side of tag □ "Claim serial number" is validated (refer to other side of tag) □ "Replacement serial number" is filled in (refer to other side of tag) □ Verify the "reason for return" is filled in (refer to other side of tag) 	Return product to: Vapor Systems Technologies, Inc. 650 Pleasant Valley Drive Springboro, Ohio 45066	Vapor Systems Technologies, Inc. 650 Pleasant Valley Drive Springboro, Ohio 45066
	1011	ıdiri	siO	λqu	i bəll	iì əd	ot gst to sbis s	idT	

Exhibit 5 VR-101 Revision X


VAULTED ABOVEGROUND STORAGE TANK CONFIGURATION (Optional)


This exhibit allows an alternate tank storage configuration for the Phase I EVR system. A vaulted aboveground storage tank (AST) may be installed in substitute for a conventional underground storage tank (UST). The figures in this exhibit provide examples of typical vaulted AST configurations.

General Specifications

Alternate typical vaulted AST configurations for the Phase I EVR Systems are shown in Figures 5-1, 5-2, 5-3, and 5-4.

Unless otherwise specified in this Executive Order (EO), the vaulted AST configuration shall comply with the applicable performance standards and performance specifications in CP-201.








Figure 5-4: Sectional Views of Typical Vaulted AST (Ventilation)

